



EAM-FM2B

FM Tuner Module

Quick Reference Guide (revision 1.10 for H/W Rev.B)



OVERVIEW

The EAM-FM2B radio tuner module is designed to receive audio and RDS information from FM radio stations.



The device has 2 independent FM radio receivers. The device supports standard commands to search for radio stations forward and backward, to tune to the frequency, to tune next or previous preset radio station, the forced mono audio mode. Up to 30 radio stations can be configured in the memory.

The device automatically transfers information about the current frequency and RDS information to the Controller.

The control, data exchange and configuration are all handled via TCP/IP protocol. The control of the device is possible via IR commands.

SPECIFICATIONS


| COMMON DATA | |
|--|---|
| Number of radio receivers | 2 |
| Supported reception range | FM 87.5 - 108.0 MHz |
| Supported RDS Functions | <ul style="list-style-type: none"> Programme Service name RadioText |
| Supported data exchange protocols | NetString |
| IR control | Yes, carrier frequency 38 kHz |
| Separate IR control commands for each FM tuner | Yes |
| Preset radio memory | 30 radio stations |
| Network interface | Ethernet (10/100) |
| Consumption current | 200 mA @ 12 VDC |

| COMMON DATA | |
|--|---|
| Supply voltage range (power connector) | 12-24 VDC |
| Power supply voltage (PoE) | IEEE 802.3af / 48 VDC Not isolated from GND |
| Operating temperature | 5° C to 45° C 40° F to 115° F |
| Operating humidity | 5 to 80% RH non-condensing |
| Enclosure | Metal with black matte finish |
| Dimensions (HWD) | 34 mm x 84 mm x 119 mm 1.34" x 3.30" x 4.69" |
| Weight | 180 g 0.40 lbs |

DEVICE CONTROL COMPONENTS

| FRONT PANEL COMPONENTS | |
|------------------------|--|
| FREQ 1 | Indicator of the current frequency at tuner 1 |
| FREQ 2 | Indicator of the current frequency at tuner 2 |
| link | Ethernet link and activity indicator |
| reset | Multifunctional button (reboot, reset, bootloader) |
| status | Indicates power status and connection to controllers |

The built-in receiver of IR commands is placed behind the cover of the front panel above the "reset" button.



| REAR PANEL COMPONENTS | |
|-----------------------|--|
| Ethernet PoE | Ethernet network RJ-45 socket (PoE) |
| +V | Power terminal (12-24 VDC) |
| GND | Power terminal (Common) |
| AUDIO 1 | 3.5 mm socket (TRS) of tuner 1 audio output signal |
| AUDIO 2 | 3.5 mm socket (TRS) of tuner 2 audio output signal |
| ANT | F-connector for antenna signal |

| LED "status" indicates the power connection and connection status with controllers | |
|--|---|
| Off | No power connected |
| Blink (1 Hz) | No connection with external controllers |
| Fast blink (4 Hz) | The device is in bootloader mode |
| On | Connected to external controllers |

| LED "link" indicates Ethernet network link and activity | |
|---|--|
| Off | No connection to Ethernet network |
| Blink | Connected to Ethernet network Receiving Ethernet data packets |
| On | Connected to Ethernet network No network activity |

Multifunctional button "reset"

To reboot the device push the button for 1 second

To reset the device to factory defaults push and hold the button for 5 seconds.

IP-address will be set to 10.0.1.101, subnet mask - to 255.255.255.0. All other settings will be set to default values

For firmware update, power off the device, push and hold the button and power the device on. Release the button after the LED "status" will start to blink fast.

The network settings of the device started in bootloader mode are: IP-address - 10.0.1.101, subnet mask - 255.255.255.0

The **PWR** terminal is designed to power the device 12-24 VDC if connected Ethernet switch has no PoE support.

The **ANT** F-connector is designed to for connection of external antenna. To receive RDS information, the signal level must be at least 15 µV.

SETUP AND CONFIGURATION

The configuration of the module is handled via web-interface.

To start working with the device:

- Connect the device to the Ethernet switch. If the switch has no PoE support, connect the power 12-24 VDC to the **PWR** terminal
- Ensure that your computer can connect to the network address 10.0.1.101 or set the TCP/IP settings of active network adaptor to: IP address - 10.0.1.100, subnet mask - 255.255.255.0
- Enter **10.0.1.101** in address bar of your web-browser
- Enter: login - **root**, password - **root**
- Configure the device settings

The web-interface contains the next web-pages:

| | |
|----------|--|
| Main | Displays the hardware revision and the firmware version |
| Settings | Network settings, IP-settings of external controller |
| Presets | Radio station presets |
| Status | Displays current TCP/IP connections and device uptime info |